

BIGshotTM

SHERRILLtree.com

Sling Replacement

Cut away old sling (tubing) being careful not to cut yourself.
Put one drop of dish-washing soap in a pint of warm water to use for sliding the new Big Shot sling onto the arms.

1. Put the Big Shot head in a table mounted vise with cushioning to avoid bending the base pipe.
2. Hold the tubing by the ends, letting the pouch relax below and remove any twist in the sling prior to the next step.
3. Wet the Big Shot arms with soapy water (use very little soap in the water), then dampen the inside of the tubes.
4. Slide ends of the sling onto the Big Shot arms about an inch or so.
5. **IMPORTANT STEP** - Milk the sling onto the arms one at a time with a pushing motion (hands must be dry). Try not to twist the sling end, but push it onto the arm with one hand and pull the leading end with the other hand.
6. If the pouch is warped, twist the sling ends while still damp. Give the sling one good pull to set it, then let it dry for 6 to 8 hours before using the Big Shot.

Have fun and be careful!



800-525-8873 SherrillTree.com